

TradeLite

Installation Instructions for Tile Roof

Clean down tray with Methylated Spirits or solvent to ensure foam guards stick and hold correctly.

